



Products

- HomeGuard™ Housewrap
- HomeGuard™ Butyl Flashing
- HomeGuard™ Seam Tape

Installation Instructions

Install housewrap over an approved exterior sheathing in “shingle-lap” fashion, with higher courses lapped over lower courses by at least two inches. Vertical seams created by ending one roll and beginning another should have an overlap of at least six inches.

Attach the housewrap so that it is flat and tight. Start with lower course, two to three feet from the corner and continue nailing or stapling as you move around the house. Fasteners must penetrate the stud or nail base material.

Secure the housewrap firmly in place by fastening it every 12” to 18” along the vertical studs using large-headed or plastic cap nails, or 1” crown staples. Use HomeGuard™ Seam Tape to seal all the seams.

Windows

Make an inverted Y cut in the housewrap at the rough opening. Then cut straight across the top and make 45° cuts from the corners to create header flap.

Fold the flaps in through the opening at the two sides and the sill, fastening them inside with staples about every six inches.

Temporarily tape the header flap up to expose nail base material. Using HomeGuard Butyl Flashing, install the sill flashing over the housewrap. Install the window per manufacturers’ instructions.

Next, install jamb flashing over side window flanges. Next, install head flashing over the top window flange and extend beyond the jamb flashing. Remove the temporary tape from header flap and fold back down over top flange. Next, seal header flap with HomeGuard Seam Tape or flashing tape.

Please see reverse side for diagram.

HomeGuard

